



COPIE	DRAWING CONTAINS INFORMATION AND DATA WHICH IS PROPRIETARY TO AERO DESIGN LTD. THIS DRAWING, OR ANY PORTION D, OR DUPLICATED IN ANY MANNER, NOR USED FOR MANUFACTURING WITHOUT THE WRITTEN CONSENT OF AERO DESIGN LTD RENCE, THE RECIPIENT AGREES TO HOLD AERO DESIGN LTD. HARMLESS FROM THE USE, OR MISUSE, OF THIS DRAWING OR TH). BY ACCEPTING	THIS DRAWING FOR
REV.	DESCRIPTION OF CHANGE	INITIALS	DATE
0	INITIAL ISSUE - CREATED FROM 95901, REV. 1	*	*

NOTES

- INSTALLATION OF MOUNTING PROVISIONS IN ACCORDANCE WITH DRAWING 95906 AND 95907 IS REQUIRED PRIOR TO THIS INSTALLATION.
- 2. REFER TO FLIGHT MANUAL SUPPLEMENT FMS959.90 FOR FLIGHT LIMITATIONS AND INFORMATION.
- 3. REFER TO INSTRUCTIONS FOR CONTINUED AIRWORTHINESS ICA959.91 FOR MAINTENANCE INFORMATION.
- 4. BASKET INSTALLATION INSTRUCTIONS:
 - A) HOOK UPPER FORWARD ATTACHMENT INTO UPPER KEYWAY IN FORWARD MOUNTING BEAM.
 - B) LIFT BASKET FROM AFT END, SLIDE LOWER FORWARD ATTACHMENT INTO LOWER KEYWAY AND PULL BASKET AFT.

01/02

- C) LIFT BASKET TO AFT MOUNTING BEAM, ENGAGE AFT ATTACHMENTS INTO KEYWAYS IN AFT BEAM.
- D) PUSH BASKET DOWN TO LOCK BASKET INTO AFT BEAM, PIN WILL SPRING INTO PLACE WITH A SNAP.
- E) CHECK THAT BASKET IS LOCKED IN PLACE BY ATTEMPTING TO LIFT AFT END OF BASKET.
- 5. WEIGHT AND BALANCE GIVEN FOR RIGHT SIDE, LATERAL ARMS FOR LEFT SIDE ARE NEGATIVE.

	WEIGHT AN	D BALA	ANCE -	- METR	RIC	
		WEIGHT	LONG ARM	ITUDINAL MOMENT	LATERAL ARM	. (NOTE 5) MOMENT
ITEM	DESCRIPTION	(kg)	(mm)	(mm-kg)	(mm)	(mm-kg)
03/04 05/06	PROVISIONS INSTALLATION CARGO BASKET ASSEMBLY	14.74 32.30	5088.3 5342.6	75010 172545	71.0 1135.4	1047 36668
01/02	CARGO BASKET INSTALLATION	47.04	5262.9	247555	801.8	37714
	CARGO (MAXIMUM, CENTERED)	136.08	5342.6	727015	1135.4	154500
	WEIGHT AND	BALAN	ICE -	STAND	ARD	
			LONG	ITUDINAL	LATERAL	. (NOTE 5)
		WEIGHT	ARM	MOMENT	ARM	MOMENT
ITEM	DESCRIPTION	(LB)	(IN)	(LB-IN)	(IN)	(LB-IN)
03/04	PROVISIONS INSTALLATION	32.5	200.33	6510.57	2.79	90.83
05/06	CARGO BASKET ASSEMBLY	71.2	210.34	14976.21	44.70	3182.64

1 95950-01-02 06 LH CARGO BASKET ASSEMBLY 1 95950-01-01 05 RH CARGO BASKET ASSEMBLY 1 95906-01-02 04 LH MOUNTING PROVISIONS INSTALLATION 1 95906-01-01 03 RH MOUNTING PROVISIONS INSTALLATION 95905-01-02 02 LH CARGO BASKET INSTALLATION 95905-01-01 01 RH CARGO BASKET INSTALLATION 02 01 PART NO. ITEM DESCRIPTION QTY QTY LIST OF MATERIALS						
1 95906-01-02 04 LH MOUNTING PROVISIONS INSTALLATION 1 95906-01-01 03 RH MOUNTING PROVISIONS INSTALLATION 95905-01-02 02 LH CARGO BASKET INSTALLATION 95905-01-01 01 RH CARGO BASKET INSTALLATION 02 01 PART NO. ITEM DESCRIPTION	1		95950-01-02	06	LH CARGO BASKET ASSEMBLY	
1 95906-01-01 03 RH MOUNTING PROVISIONS INSTALLATION 95905-01-02 02 LH CARGO BASKET INSTALLATION 95905-01-01 01 RH CARGO BASKET INSTALLATION 02 01 PART NO. ITEM DESCRIPTION		1	95950-01-01	05	RH CARGO BASKET ASSEMBLY	
95905-01-02 02 LH CARGO BASKET INSTALLATION 95905-01-01 01 RH CARGO BASKET INSTALLATION 02 01 PART NO. ITEM DESCRIPTION	1		95906-01-02	04	LH MOUNTING PROVISIONS INSTALLATION	
95905-01-01 01 RH CARGO BASKET INSTALLATION 02 01 PART NO. ITEM DESCRIPTION		1	95906-01-01	03	RH MOUNTING PROVISIONS INSTALLATION	
02 01 PART NO. ITEM DESCRIPTION			95905-01-02	02	LH CARGO BASKET INSTALLATION	
			95905-01-01	01	RH CARGO BASKET INSTALLATION	
QTY QTY LIST OF MATERIALS	02	01	PART NO.	ITEM	DESCRIPTION	
	QTY	QTY QTY LIST OF MATERIALS			LIST OF MATERIALS	

APPROVALS	DATE	/.
RAWN: JEFF CLARKE	31 JAN 2014	
HECKED: JASON REKVE		_
UNLESS OTHERWISE	SPECIFIED	

DIMENSIONS ARE IN INCHES. TOLERANCES ON: DECIMALS **ANGLES** x.xxx ±0.010 ±1/2°

CARGO BASKET INSTALLATION

CARGO (MAXIMUM, CENTERED)

x.xx ±0.03 ±0.1

	\mathcal{M}	
/		

103.7

300.0

207.20

210.34

AERO DESIGN

31.57

3273.47

44.70 13410.00

9888A MALASPINA ROAD POWELL RIVER, BC, CANADA, V8A 0G3 TEL: 604.483.2376 www.aerodesign.ca

BELL 429 - S/N 57081 & SUB. QUICK RELEASE CARGO BASKET CARGO BASKET INSTALLATION

21486.78

63102.00

DWG. SIZE DWG. NO. REV. NOT TO SCALE 95905 SHEET 3 OF 3